

Generation Line spare part manual

Manual date: 2016-05-25

DAVID

Copyright © 2015 David Health Solutions Ltd.

1	G110 parts	5
1.1	G110 manual main assembly	6
1.2	G110 automatic main assembly	7
1.3	G110 base machine	8
1.4	G110 movement arm	9
1.5	G110 measuring unit	10
1.6	G110 isometric lock	11
2	G120 parts	12
2.1	G120 manual main assembly	13
2.2	G120 automatic main assembly	14
2.3	G120 base machine	15
2.4	G120 measurement unit	16
2.5	G120 isometric lock	17
2.6	G120 seat assembly	18
2.7	G120 automatic shoulder fixation	19
2.8	G120 manual shoulder fixation	20
2.9	G120 EVE arm automatic	21
2.10	G120 EVE arm manual	22
3	G130 parts	23
3.1	G130 automatic main assembly	24
3.2	G130 base machine	25
3.3	G130 movement arm assembly	26
3.4	G130 measuring unit	27
3.5	G130 isometric lock	28
4	G140 parts	29
4.1	G140 manual main assembly	30
4.2	G140 automatic main assembly	31
4.3	G140 main frame	32
4.4	G140 movement arm	33
4.5	G140 measurement unit	34
4.6	G140 isometric lock	35
4.7	G140 manual seat	36
4.8	G140 automatic seat	37
4.9	G140 chest support	38
4.10	G140 EVE arm	39
5	G150 parts	40
5.1	G150 manual main assembly	41

5.2	G150 automatic main assembly	42
5.3	G150 base machine	43
5.4	G150 movement arm	44
5.5	G150 counter weight	45
5.6	G150 measurement unit	46
5.7	G150 index lever	47
5.8	G150 isometric lock	48
5.9	G150 secondary axle	49
5.10	G150 manual seat assembly	50
5.11	G150 automatic seat assembly	51
6	G160 parts	52
6.1	G160 manual main assembly	53
6.2	G160 automatic main assembly	54
6.3	G160 base machine	55
6.4	G160 movement arm	56
6.5	G160 measurement axle	57
6.6	G160 manual seat assembly	58
6.7	G160 automatic seat assembly	59
6.8	G160 chest support assembly	60
7	Generation Line common parts	61
7.1	G110/G130 manual Hip-Fix	62
7.2	G110/G130 automatic Hip-Fix	63
7.3	G110/G130 manual seat	64
7.4	G110/G130 automatic seat	65
7.5	G110/G130 EVE arm	66
7.6	Angle sensor assembly	67
7.7	Measurement axle cable housing assembly	68
7.8	Isometric lock control unit	69
7.9	5/200kg weight stack assembly	70
7.10	2.5/100kg weight stack assembly	71
7.11	1/25kg weight stack assembly	72
7.12	RMA 1-12 step	73
7.13	RMA 1-8 step	74

1 G110 parts


5 of 75


- [G110 manual main assembly](#)
- [G110 automatic main assembly](#)
- [G110 base machine](#)
- [G110 movement arm](#)
- [G110 measuring unit](#)
- [G110 isometric lock](#)

Please also look at the common parts:

- [G110/G130 manual Hip-Fix](#)
- [G110/G130 automatic Hip-Fix](#)
- [G110/G130 manual seat](#)
- [G110/G130 automatic Hip-Fix](#)
- [G110/G130 EVE arm](#)
- [Angle sensor assembly](#)
- [Measurement axle cable housing assembly](#)
- [Isometric lock control unit](#)
- [2.5/100kg weight stack assembly](#)
- [RMA 1-12 step](#)


Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30000	Angle sensor assembly
3	S30209	G110 Base machine
4	S30226	G110 Isometric Lock
5	S30208	G110 Measuring unit
6	S30225	G110 Movement arm
7	S30201	G110/G130 EVE arm
8	S30262	G110/G130 Manual seat
9	S30490	Isometric lock control unit
10	S30263	Manual Hip-Fix G-Line
11	S30214	RMA 1-12 step






Ind.	Code	Description
1	S30000	Angle sensor assembly
2	S30201	G110/G130 EVE arm
3	S30208	G110 Measuring unit
4	S30209	G110 Base machine
5	S30211	Automatic Hip-Fix G-Line
6	S30212	G110/G130 Automatic seat
7	S30213	2.5/100kg Weight Stack
8	S30214	RMA 1-12 step
9	S30225	G110 Movement arm
10	S30226	G110 Isometric lock
11	S30490	Isometric lock control G110

G110 Automatic	24/2013=>
Description	Model year




Ind.	Code	Description
1	S30116	Axle
2	S30119	Axle
3	S30125	Back cover
4	S04892	Ball bearing
5	S30131	Cover
6	S30132	Foot
7	S30505	Front Cover G110/G130
8	S30117	Mounting plate
9	S00466	Nut
10	S06767	Outer snap ring
11	S30113	Pad, back
12	S30133	Pin
13	S30128	Power supply 24V
14	S30126	Power supply cover
15	S30130	Protective cap
16	S30118	Pulley frame assembly
17	S02679	Retaining ring
18	S30129	Rivet
19	S00558	Screw
20	S00932	Screw
21	S03228	Screw
22	S07966	Screw
23	S30122	Screw
24	S30123	Screw
25	S30114	Seat frame
26	S30134	Side profile
27	S30121	Sleeve
28	S30127	Top cover
29	S01634	Washer
30	S30112	Weight stack frame
31	S30120	Wire pulley
32	S30115	Wire pulley assembly


G110 Base machine	24/2013=>
Description	Model year



Ind.	Code	Description
1	S30234	Center mark
2	S30093	Counterweight
3	S00520	Flanged bushing
4	S30092	Flanged bushing G110
5	S30095	Hub cover
6	S30089	Index plate
7	S00421	Indexing plunger yellow
8	S30091	Indicator
9	S30094	Indicator
10	S30087	Movement arm
11	S08834	Nut
12	S30088	Pad, movement arm
13	S06025	Screw
14	S09217	Screw
15	S30096	Screw

G110 Movement arm	24/2013=>
Description	Model year





Ind.	Code	Description
1	S01144	Bushing
2	S30102	Bushing
3	S30101	Control lever
4	S30097	Isometric lock frame
5	S30099	Locking pin
6	S30079	Nut
7	S01910	Outer snap ring
8	S30052	Pin
9	S30031	Roll pin
10	S04808	Screw
11	S30100	Screw
12	S30098	Spring

G110 Isometric Lock	24/2013=>
Description	Model year

2 G120 parts


12 of 75

- [G120 manual main assembly](#)
- [G120 automatic main assembly](#)
- [G120 base machine](#)
- [G120 measurement unit](#)
- [G120 isometric lock](#)
- [G120 seat assembly](#)
- [G120 automatic shoulder fixation](#)
- [G120 manual shoulder fixation](#)
- [G120 EVE arm automatic](#)
- [G120 EVE arm manual](#)


Please also look at the common parts:

- [2.5/100kg weight stack assembly](#)

Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30337	G120 Base machine
3	S30546	G120 EVE arm manual
4	S30365	G120 Isometric lock Assy
5	S30545	G120 Manual shoulder-fix
6	S30297	G120 Measurement Unit
7	S30348	G120 Seat Assy
8	S30369	Stand





G120 Manual	2013
Description	Model year




Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30318	Automatic shoulder fix
3	S30330	G120 Automatic EVE arm
4	S30337	G120 Base machine
5	S30365	G120 Isometric lock assy
6	S30297	G120 Measurement Unit
7	S30348	G120 Seat assy
8	S30369	Stand

G120 Automatic	2013
Description	Model year




Ind.	Code	Description
1	S30345	Angle gauge
2	S30125	Back cover
3	S30132	Foot
4	S30340	G120 Front cover
5	S30490	G120 Isometric lock control
6	S30339	G120 Wire pulley set
7	S30338	Lower frame
8	S30341	Plug
9	S30126	Power supply cover
10	S06025	Screw
11	S07966	Screw
12	S30344	Seat frame cover Left
13	S30343	Seat frame cover Right
14	S30134	Side profile
15	S30346	Support beam
16	S30342	Support frame
17	S30127	Top cover
18	S30112	Weight stack frame
19	S30115	Wire pulley assembly

G120 Base machine	2013
Description	Model year




Ind.	Code	Description
1	S30302	Ball bearing
2	S02224	Ball bearing
3	S30305	Ball bearing
4	S30306	Bearing collar
5	S05302	Bearing housing
6	S30080	Bearing housing
7	S30303	Cable cover
8	S30304	Cable cover frame
9	S30299	Cam catcher
10	S30309	Catch block
11	S30314	Draw collar
12	S30313	Draw plate
13	S30308	G120 Cam
14	S30300	Index plate
15	S30312	Index plunger
16	S30311	Indicator arrow
17	S05682	Key
18	S30298	Measuring axle
19	S02382	Nut
20	S05694	Nut
21	S01898	Outer snap ring
22	S05168	RETAINING RING
23	S05448	RETAINING RING
24	S00364	Screw
25	S04808	Screw
26	S07966	Screw
27	S09143	Screw
28	S30301	Secondary axle
29	S30316	Set screw
30	S30310	Spacer
31	S30315	Spring
32	S30307	Support plate G120




Ind.	Code	Description
1	S30104	Ball joint
2	S30358	Ball joint
3	S01144	Bushing
4	S30102	Bushing
5	S30101	Control lever
6	S30366	G120 Isometric lock frame
7	S30099	Locking pin
8	S07358	Nut
9	S30079	Nut
10	S30052	Pin
11	S30367	Push rod
12	S30031	Roll pin
13	S30100	Screw
14	S30098	Spring

G120 Isometric lock	2013
Description	Model year




Ind.	Code	Description
1	S00248	Attachment (Gas spring)
2	S30023	Axle
3	S30360	Back pad
4	S30358	Ball joint
5	S30324	Bushing
6	S30036	Cap. control lever
7	S30002	Control lever, two-finger
8	S30359	Cover
9	S00520	Flanged bushing
10	S01144	Flanged bushing
11	S07782	Flanged bushing
12	S30362	Flexible element
13	S30357	Fork
14	S30041	Gas shock, lockable
15	S02035	Grip
16	S00368	Handgrip
17	S30350	Knee fix frame
18	S30351	Knee pad
19	S30355	Knob
20	S30353	Lever, Left
21	S30356	Lever, right
22	S00088	Nut
23	S02382	Nut
24	S05694	Nut
25	S07358	Nut
26	S01910	Outer snap ring
27	S03099	Outer snap ring
28	S30052	Pin
29	S30354	Plunger
30	S30031	Roll pin
31	S30361	Roll pin
32	S00558	Screw
33	S01665	Screw
34	S02005	Screw
35	S04031	Screw
36	S06025	Screw
37	S09636	Screw
38	S30078	Screw
39	S30363	Screw
40	S30532	Screw
41	S30349	Seat frame
42	S30352	Seat pad
43	S03643	Spring plunger

G120 Seat assy	2013
Description	Model year




Ind.	Code	Description
1	S30323	Actuator bracket
2	S00248	Attachment (Gas spring)
3	S30321	Back rest frame
4	S30326	Bracket
5	S01144	Bushing
6	S30324	Bushing
7	S30205	Control lever
8	S30325	Cover
9	S30237	Gas shock, lockable
10	S30231	Gas spring shell
11	S02035	Grip
12	S30320	Guide rod
13	S30061	Index sticker
14	S30232	Joint sleeve
15	S30035	Linear Actuator S220
16	S01910	Outer snap ring
17	S30322	Pad
18	S05543	Pad, back support
19	S30052	Pin
20	S30233	Pin
21	S30236	Roll pin
22	S00364	Screw
23	S00489	Screw
24	S00558	Screw
25	S03286	Screw
26	S07687	Screw
27	S09636	Screw
28	S30229	Shoulder Fix
29	S30319	Slide block
30	S00813	Wire,

Automatic shoulder fix	13/2013
Description	Model year



Ind.	Code	Description
1	S30535	Adjuster screw
2	S00248	Attachment (Gas spring)
3	S30321	Back rest frame
4	S03572	Ball bearing
5	S30326	Bracket
6	S01144	Bushing
7	S30324	Bushing
8	S30205	Control lever
9	S30325	Cover
10	S30237	Gas shock, lockable
11	S30231	Gas spring shell
12	S02035	Grip
13	S30320	Guide rod
14	S00220	Hand wheel
15	S30061	Index sticker
16	S30232	Joint sleeve
17	S00537	Nut, adjuster screw
18	S01910	Outer snap ring
19	S30322	Pad
20	S05543	Pad, back support
21	S30052	Pin
22	S30233	Pin
23	S30537	Restrictor
24	S30424	RETAINING RING
25	S30236	Roll pin
26	S00364	Screw
27	S00489	Screw
28	S00558	Screw
29	S03286	Screw
30	S09636	Screw
31	S30229	Shoulder Fix
32	S30319	Slide block
33	S03643	Spring plunger
34	S30536	Support sleeve
35	S00813	Wire,


G120 Manual shoulder-fix	2013
Description	Model year



Ind.	Code	Description
1	S30329	E-Stop
2	S30334	E-Stop case
3	S30333	E-Stop casing
4	S30335	E-Stop cover
5	S06559	End cap
6	S30332	EVE arm Automatic
7	S30206	EVE Display unit
8	S30331	EVE foot
9	S30204	EVE Plate
10	S30203	EVE Spacer
11	S05694	Nut
12	S04716	Screw
13	S04808	Screw
14	S05782	Screw
15	S30207	Screw

G120 EVE Arm Automatic	2013
Description	Model year

Ind.	Code	Description
1	S06559	End cap
2	S30543	EVE Arm manual
3	S30206	EVE Display unit
4	S30331	EVE foot
5	S30204	EVE Plate
6	S30203	EVE Spacer
7	S05694	Nut
8	S04808	Screw
9	S05782	Screw
10	S30207	Screw



G120 Manual EVE arm	2013
Description	Model year

3 G130 parts


23 of 75

- [G130 automatic main assembly](#)
- [G130 base machine](#)
- [G130 movement arm assembly](#)
- [G130 measuring unit](#)
- [G130 isometric lock](#)

Please also look at the common parts:



- [G110/G130 manual Hip-Fix](#)
- [G110/G130 automatic Hip-Fix](#)
- [G110/G130 manual seat](#)
- [G110/G130 automatic Hip-Fix](#)
- [G110/G130 EVE arm](#)
- [Angle sensor assembly](#)
- [Measurement axle cable housing assembly](#)
- [Isometric lock control unit](#)
- [2.5/100kg weight stack assembly](#)
- [RMA 1-12 step](#)

3.1 G130 automatic main assembly




Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30211	Automatic Hip-Fix G-Line
3	S30212	G110/G130 Automatic seat
4	S30201	G110/G130 EVE arm
5	S30210	G130 Base machine
6	S30215	G130 Measuring unit
7	S30216	G130 Movement arm assy
8	S30240	Isometric Lock assy
9	S30490	Isometric Lock control unit
10	S30214	RMA 1-12 step

G130 Automatic	24/13 ==>
Description	Model year




Ind.	Code	Description
1	S30125	Back cover
2	S30113	Back Pad G110/G130
3	S30131	Cover
4	S30124	Front Cover G110/G130
5	S30126	Low cover
6	S30220	Machine Foot
7	S30133	Pin
8	S30128	Power Supply 24V
9	S30130	Protective cap
10	S30118	Pulley frame assembly
11	S30129	Rivet
12	5397	Screw
13	S00558	Screw
14	S03228	Screw
15	S07966	Screw
16	S30114	Seat frame
17	S30134	Side profile
18	S30127	Top cover
19	S30112	Weight stack frame
20	S30115	Wire pulley assembly

G130 Base Machine	24/13 =>
Description	Model year




Ind.	Code	Description
1	S00248	Attachment (Gas spring)
2	S01144	Bushing
3	S30234	Center mark
4	S30205	Control lever
5	S30095	Cover
6	S30028	End cap
7	S30228	G130 Counterweight
8	S30227	G130 Movement arm frame
9	S30237	Gas shock, lockable
10	S30231	Gas spring shell
11	S02035	Grip
12	S30094	Indicator
13	S30232	Joint sleeve
14	S08834	Nut
15	S01910	Outer snap ring
16	S30322	Pad
17	S30052	Pin
18	S30233	Pin
19	S30236	Roll pin
20	S00364	Screw
21	S06025	Screw
22	S06340	Screw
23	S09636	Screw
24	S30096	Screw
25	S30229	Shoulder Fix
26	S30230	Upper back pad G130
27	S00813	Wire.

G130 Movement arm assy	24/13 =>
Description	Model year



Ind.	Code	Description
1	S30274	Angle gauge
2	S30000	Angle sensor assembly
3	S02224	Ball bearing
4	S30074	Bearing housing
5	S30080	Bearing housing
6	S30222	Cam
7	S30324	G130 Measuring axle
8	S05694	Nut
9	S01898	Outer snap ring
10	S05168	RETAINING RING
11	S04808	Screw
12	S09143	Screw
13	S30200	Screw
14	S30086	Sleeve
15	S30221	Support plate G130

G130 Measuring unit	24/13 =>
Description	Model year



Ind.	Code	Description
1	S30102	Bushing
2	S30238	Control lever
3	S01144	Flanged bushing
4	S30239	Isometric lock frame
5	S30099	Locking pin
6	S30079	Nut
7	S01910	Outer snap ring
8	S30052	Pin
9	S30236	Roll pin
10	S30100	Screw
11	S30098	Spring

G130 Isometric Lock	24/13 =>
Description	Model year


4 G140 parts

29 of 75


- [G140 manual main assembly](#)
- [G140 automatic main assembly](#)
- [G140 main frame](#)
- [G140 movement arm](#)
- [G140 measurement unit](#)
- [G140 isometric lock](#)
- [G140 manual seat](#)
- [G140 automatic seat](#)
- [G140 chest support](#)
- [G140 EVE arm](#)

Please also look at the common parts:

- [Angle sensor assembly](#)
- [Measurement axle cable housing assembly](#)
- [Isometric lock control unit](#)
- [1/25kg weight stack assembly](#)
- [RMA 1-12 step](#)




Ind.	Code	Description
1	S30195	1/25kg Weight Stack Assy
2	S30492	G140 Base machine
3	S30283	G140 Chest support assy
4	S30491	G140 EVE arm
5	S30278	G140 Isometric lock assy
6	S30490	G140 Isometric lock control
7	S30494	G140 Manual seat assy
8	S30269	G140 Measuring unit assy
9	S30265	G140 Movement arm assy
10	S30268	RMA 1-8 step
11	S30369	Stand




Ind.	Code	Description
1	S30195	1/25kg Weight Stack Assy
2	S30000	Angle sensor assembly
3	S30491	EVE arm
4	S30493	G140 Automatic seat assy
5	S30492	G140 Base machine
6	S30283	G140 Chest support assy
7	S30278	G140 Isometric lock assy
8	S30269	G140 Measuring unit assy
9	S30265	G140 Movement arm assy
10	S30490	Isometric Lock control G140
11	S30268	RMA 1-8 step
12	S30369	Stand

G140 Automatic	2013
Description	Model year




Ind.	Code	Description
1	S30125	Back cover
2	S30132	Foot
3	S30296	Front cover G140
4	S30126	Low cover
5	S30128	Power 24V
6	S30118	Pulley frame assembly
7	S07966	Screw
8	S30134	Side profile
9	S30127	Top cover
10	S30112	Weight stack frame
11	S30115	Wire pulley assembly

G140 Main frame	1/2013
Description	Model year




Ind.	Code	Description
1	S30234	Center mark
2	S30095	Cover
3	S30267	G140 Counterweight
4	S30094	Indicator
5	S30266	Movement arm frame
6	S08834	Nut
7	S00701	Pad, head support
8	S00364	Screw
9	S06025	Screw
10	S30096	Screw

G140 Movement arm	24/13 =>
Description	Model year




Ind.	Code	Description
1	S30274	Angle gauge
2	S02224	Ball bearing
3	S30074	Bearing housing
4	S30080	Bearing housing
5	S30090	Cable housing
6	S30082	Cable housing assembly
7	S06959	Cover
8	S30083	Cover sleeve
9	S30271	G140 Cam
10	S30270	G140 Measuring axle
11	S05682	Key
12	S30084	Mounting plate
13	S05694	Nut
14	S30079	Nut
15	S01534	Outer snap ring
16	S01898	Outer snap ring
17	S30085	Outer snap ring
18	S05168	RETAINING RING
19	S04808	Screw
20	S06340	Screw
21	S07966	Screw
22	S09143	Screw
23	S30273	Screw
24	S30086	Sleeve
25	S30272	Support plate G140

G140 Measuring unit assy	15/14 =>
Description	Model year




Ind.	Code	Description
1	S30102	Bushing
2	S30238	Control lever
3	S01144	Flanged bushing
4	S30277	G140 Isometric lock frame
5	S30099	Locking pin
6	S30079	Nut
7	S30052	Pin
8	S30236	Roll pin
9	S30100	Screw
10	S30098	Spring

G140 Isometric Lock assy	
Description	Model year




Ind.	Code	Description
1	S02224	Ball bearing
2	S30244	Collar
3	S30258	Cover
4	S30540	End cap
5	S30544	End cap
6	S30538	G140/G160 MAN Seat frame
7	S30541	Gas shock
8	S30312	Index plunger
9	S30259	Knob
10	S30542	Knob
11	S30032	Linear bearing + guide
12	S30257	Lock lever
13	S30220	Machine foot
14	S05694	Nut
15	S01898	Outer snap ring
16	S05168	RETAINING RING
17	S00558	Screw
18	S03228	Screw
19	S03482	Screw
20	S05782	Screw
21	S30078	Screw
22	S30256	Seat cushion
23	S30255	Seat pivot
24	S30242	Seat stem
25	S30243	Seat stem cover
26	S01556	Washer




***	2013
Description	Model year

4.8 G140 automatic seat




Ind.	Code	Description
1	S02224	Ball bearing
2	S30244	Collar
3	S30253	Collar
4	S30258	Cover
5	S30132	Foot
6	S30241	G140/G160 AT seat frame
7	S02035	Grip
8	S30245	Idler assy
9	S30246	Idler frame
10	S30259	Knob
11	S30035	Linear Actuator S220
12	S30032	Linear bearing + guide
13	S30257	Lock lever
14	S05694	Nut
15	S07358	Nut
16	S30079	Nut
17	S01898	Outer snap ring
18	S03099	Outer snap ring
19	S05168	RETAINING RING
20	S00558	Screw
21	S30328	Screw
22	S03482	Screw
23	S04808	Screw
24	S05397	Screw
25	S05782	Screw
26	S06796	Screw
27	S09217	Screw
28	S30078	Screw
29	S30200	Screw
30	S30254	Screw
31	S30261	Screw
32	S30256	Seat cushion
33	S30255	Seat pivot
34	S30242	Seat stem
35	S30243	Seat stem cover
36	S30249	Spacer
37	S30247	Spring
38	S30251	Support bracket
39	S01556	Washer
40	S30252	Wire connector
41	S30250	Wire cover
42	S30248	Wire guide
43	S30260	Wire support

Automatic seat G140/G160	24/13 =>
Description	Model year



Ind.	Code	Description
1	S00652	Attachment
2	S07321	Axle
3	S00653	Bushing
4	S30028	End cap
5	S07782	Flanged bushing
6	S30282	G140 Chest pad
7	S30281	G140 Chest support frame
8	S30280	Handle
9	S02544	Indexing plunger
10	S30259	Knob
11	S09568	Mounting bracket
12	S04753	Rod, chest support
13	S03806	Screw
14	S04031	Screw
15	S04668	Screw
16	S05048	Screw
17	S07209	Screw
18	S30200	Screw
19	S03616	Set screw
20	S06049	Washer

G140 Chest support	
Description	Model year



Ind.	Code	Description
1	S30286	Bracket
2	S30287	Cushion
3	S06559	End cap
4	S30206	EVE Display unit
5	S30282	EVE Foot
6	S30204	EVE Plate
7	S30203	EVE Spacer
8	S00118	Flanged bushing
9	S30285	Moving EVE strut
10	S05694	Nut
11	S30283	Rigid EVE strut
12	S01933	Roll pin
13	S00932	Screw
14	S03806	Screw
15	S05048	Screw
16	S30200	Screw
17	S30207	Screw
18	S30284	Slide ring
19	S30205	Thread block
20	S01123	Washer
21	S02528	Washer

G140 EVE Terminal	
Description	Model year


5 G150 parts

40 of 75


- [G150 manual main assembly](#)
- [G150 automatic main assembly](#)
- [G150 base machine](#)
- [G150 movement arm](#)
- [G150 counter weight](#)
- [G150 measurement unit](#)
- [G150 index lever](#)
- [G150 isometric lock](#)
- [G150 secondary axle](#)
- [G150 manual seat assembly](#)
- [G150 automatic seat assembly](#)

Please also look at the common parts:

- [Angle sensor assembly](#)
- [Measurement axle cable housing assembly](#)
- [Isometric lock control unit](#)
- [2.5/100kg weight stack assembly](#)




Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30000	Angle sensor assembly
3	S30502	Counter weight assy
4	S30489	G150 Base machine
5	S30497	G150 Isometric lock assy
6	S30490	G150 Isometric lock control
7	S30503	G150 Manual seat assy
8	S30496	G150 Measurement Unit
9	S30501	Indexing handle assy
10	S30500	Movement arm assy
11	S30499	Secondary axle assy




Ind.	Code	Description
1	S30213	2.5/100kg Weight Stack
2	S30000	Angle sensor assembly
3	S30502	Counter weight assy
4	S30504	G150 Automatic seat assy
5	S30489	G150 Base machine
6	S30497	G150 Isometric lock assy
7	S30496	G150 Measurement Unit
8	S30501	Indexing handle assy
9	S30490	Isometric lock control unit
10	S30500	Movement arm assy
11	S30499	Secondary axle assy

G150 Automatic	2013
Description	Model year




Ind.	Code	Description
1	S30125	Back cover
2	S30373	Front beam
3	S30372	Front cover G150
4	S30126	Low cover
5	S30220	Machine foot
6	S30133	Pin
7	S30341	Plug
8	S30129	Rivet
9	S06025	Screw
10	S07966	Screw
11	S30363	Screw
12	S30374	Seat frame cover, left
13	S30375	Seat frame cover, right
14	S30134	Side profile
15	S30369	Stand
16	S30127	Top cover
17	S30112	Weight stack frame
18	S30376	Wire connector
19	S30115	Wire pulley assembly
20	S30371	Wire pulley set

G150 Base Machine	2013
Description	Model year




Ind.	Code	Description
1	S30414	Adjustment tube
2	S30413	Axle
3	S03572	Ball bearing
4	S07503	Ball bearing
5	S00600	Bevel gear
6	S30426	Bracket
7	S30419	Bushing
8	S30234	Center mark
9	S30417	End cap
10	S30425	Gear
11	S00220	Hand wheel
12	S30420	Hub cover
13	S30094	Indicator
14	S05682	Key
15	S03099	Outer snap ring
16	S30416	Pad, shoulder support
17	S30423	Pinion axle
18	S02341	RETAINING RING
19	S30424	RETAINING RING
20	S00191	Roll pin
21	S30031	Roll pin
22	S30422	Roll pin
23	S04031	Screw
24	S06025	Screw
25	S30421	Screw
26	S30415	Shoulder support
27	S30421	Sleeve
28	S30427	Stem
29	S30418	Thread block
30	S00604	Trapezoidal screw, left
31	S00619	Trapezoidal screw, right

G150 Movement arm	2013
Description	Model year




Ind.	Code	Description
1	S30444	Balancer
2	S03572	Ball bearing
3	S00472	Bearing assembly
4	S30440	Bracket
5	S30447	Connecting rod
6	S00466	Nut
7	S07358	Nut
8	S30424	RETAINING RING
9	S04808	Screw
10	S09143	Screw
11	S30445	Screw
12	S30446	Screw
13	S30443	Threaded rod
14	S30441	Weight frame
15	S30442	Weight plate

G150 Counter weight	2013
Description	Model year




Ind.	Code	Description
1	S02224	Ball bearing
2	S30305	Ball bearing
3	S30306	Bearing collar
4	S05302	Bearing housing
5	S30080	Bearing housing
6	S30299	Cam catcher
7	S30377	Cam G150
8	S30309	Catch block
9	S05682	Key
10	S30298	Measuring axle
11	S05694	Nut
12	S01898	Outer snap ring
13	S05168	RETAINING RING
14	S00364	Screw
15	S04808	Screw
16	S09143	Screw
17	S30316	Set screw
18	S30378	Support plate G150

G150 Measurement Unit	2013
Description	Model year



Ind.	Code	Description
1	S30430	Bracket
2	S30432	Draw bar
3	S00520	Flanged bushing
4	S01144	Flanged bushing
5	S30259	Knob
6	S30431	Lever arm
7	S30433	Lock flange
8	S30437	Lock frame
9	S00088	Nut
10	S00925	Outer snap ring
11	S30436	Pin
12	S30435	Roll pin
13	S03482	Screw
14	S05397	Screw
15	S07116	Screw
16	S30078	Screw
17	S03643	Spring plunger
18	S30434	Stopper
19	S30438	Thread block
20	S01556	Washer


G150 Index Lever	2013
Description	Model year




Ind.	Code	Description
1	S30102	Bushing
2	S30101	Control lever
3	S01144	Flanged bushing
4	S30381	Isometric lock frame G150
5	S30099	Locking pin
6	S30079	Nut
7	S30052	Pin
8	S30031	Roll pin
9	S04808	Screw
10	S30100	Screw
11	S30098	Spring

G150 Isometric Lock	2013
Description	Model year

Ind.	Code	Description
1	S07047	Ball bearing
2	S02224	Ball bearing
3	S30411	Draw collar
4	S30313	Draw plate
5	S30300	Index plate
6	S30312	Index plunger
7	S02382	Nut
8	S01898	Outer snap ring
9	S05448	RETAINING RING
10	S09127	Roll pin
11	S30410	Secondary axle
12	S30316	Set screw
13	S30315	Spring




G150 Secondary axle	2013
Description	Model year



Ind.	Code	Description
1	S08294	Attachment
2	S00248	Attachment (Gas spring)
3	S30386	Back plate
4	S30388	Bolt
5	S30036	Cap. control lever
6	S30393	Control Lever
7	S30399	Draw plate
8	S30394	End cap (open)
9	S30396	EVE arm
10	S30206	EVE Display unit
11	S00520	Flanged bushing
12	S02701	Flanged bushing
13	S07782	Flanged bushing
14	S30385	Front frame
15	S00798	Gas shock, lockable
16	S30392	Hand Lever
17	S30550	Index plate
18	S30070	Indexing plunger
19	S30407	Indicator arrow
20	S30401	Knee pad, left
21	S30402	Knee pad, right
22	S30390	Knee support
23	S30549	Lever
24	S30551	Lever
25	S30032	Linear bearing + guide
26	S07358	Nut
27	S09785	Nut
28	S03099	Outer snap ring
29	S30391	Pin
30	S30398	Pin
31	S30435	Roll pin
32	S00157	Screw
33	S04808	Screw
34	S05782	Screw
35	S06025	Screw
36	S06794	Screw
37	S06915	Screw
38	S09636	Screw
39	S30096	Screw
40	S30122	Screw
41	S30261	Screw
42	S30408	Screw
43	S30389	Seat frame
44	S30397	Seat pad
45	S30395	Shim
46	S30387	Slide plate
47	S30400	Spacer
48	S01556	Washer
49	S02477	Washer

G150 Manual seat assy	2013
Description	Model year



Ind.	Code	Description
1	S00248	Attachment (Gas spring)
2	S30386	Back plate
3	S00472	Bearing assembly
4	S30388	Bolt
5	S30403	Bracket
6	S30405	Bracket
7	S30036	Cap, control lever
8	S30002	Control lever, two-finger
9	S30399	Draw plate
10	S30394	End cap (open)
11	S30396	EVE arm
12	S00520	Flanged bushing
13	S07782	Flanged bushing
14	S30385	Front frame
15	S00798	Gas shock, lockable
16	S30407	Indicator arrow
17	S30401	Knee pad, left
18	S30402	Knee pad, right
19	S30390	Knee support
20	S30392	Lever
21	S30406	Linear actuator
22	S30032	Linear bearing + guide
23	S07358	Nut
24	S09785	Nut
25	S30399	Outer snap ring
26	S30391	Pin
27	S30398	Pin
28	S04808	Screw
29	S05782	Screw
30	S06025	Screw
31	S06794	Screw
32	S06796	Screw
33	S06915	Screw
34	S09217	Screw
35	S09636	Screw
36	S30096	Screw
37	S30122	Screw
38	S30261	Screw
39	S30408	Screw
40	S30389	Seat frame
41	S30397	Seat pad
42	S30404	Set screw
43	S30395	Shim
44	S30387	Slide plate
45	S30400	Spacer
46	S01556	Washer
47	S02477	Washer

G150 Seat frame	2013
Description	Model year

6 G160 parts


52 of 75

- [G160 manual main assembly](#)
- [G160 automatic main assembly](#)
- [G160 base machine](#)
- [G160 movement arm](#)
- [G160 measurement axle](#)
- [G160 manual seat assembly](#)
- [G160 automatic seat assembly](#)
- [G160 chest support assembly](#)

Please also look at the common parts:


- [Angle sensor assembly](#)
- [1/25kg weight stack assembly](#)

Ind.	Code	Description
1	S30195	1/25kg Weight Stack Assy
2	S30000	Angle sensor assembly
3	S30517	Chest Support Assembly
4	S30515	G160 Base machine
5	S30520	G160 Manual seat assy
6	S30518	G160 Measuring axle
7	S30519	G160 Movement arm




G160 Manual	2013
Description	Model year

Ind.	Code	Description
1	S30195	1/25kg Weight Stack Assy
2	S30000	Angle sensor assembly
3	S30517	Chest Support Assembly
4	S30516	G160 Automatic seat
5	S30515	G160 Base machine
6	S30518	G160 Measuring axle
7	S30519	G160 Movement arm




G160 Automatic	2013
Description	Model year




Ind.	Code	Description
1	S30512	Axle
2	S30125	Back cover
3	S30513	Counter weight
4	S30206	EVE Display unit
5	S30505	Front cover G160
6	S30509	Front frame
7	S30126	Low cover
8	S30220	Machine foot
9	S07358	Nut
10	S30133	Pin
11	S30128	Power 24V
12	S30508	Pulley bracket
13	S30506	Pulley frame
14	S30118	Pulley frame assembly
15	S30510	Rear cover
16	S00558	Screw
17	S05782	Screw
18	S07966	Screw
19	S30030	Screw
20	S30134	Side profile
21	S30369	Stand
22	S30127	Top cover
23	S30511	Top cover
24	S30112	Weight stack frame
25	S30507	Wire cable wheel
26	S30115	Wire pulley assembly

G160 Base machine	2013
Description	Model year



Ind.	Code	Description
1	S30475	Adjustment tube
2	S00077	Bearing
3	S00653	Bushing
4	S30487	Collar
5	S06559	End cap
6	S30488	End cap with hole
7	S00220	Hand wheel
8	S30478	Head pad
9	S30480	Hub
10	S30485	Key
11	S30484	Key bracket
12	S08834	Nut
13	S30482	Pad
14	S30476	Pad frame
15	S30481	Pad plate
16	S30483	RETAINING RING
17	S04031	Screw
18	S30197	Screw
19	S30198	Screw
20	S30261	Screw
21	S30486	Set screw
22	S30477	Thread block
23	S30479	Trapezoidal screw

G160 Movement arm	2013
Description	Model year




Ind.	Code	Description
1	S30473	Angle gauge
2	S05640	Ball Bearing
3	S30460	Ball bearing
4	S01874	Bearing
5	S30463	Bearing assembly
6	S30468	Cable cover
7	S05792	Cable housing
8	S30461	Cam
9	S30462	Cam frame
10	S30472	Cover
11	S06001	Hex nut
12	S30470	Holder
13	S30459	Index plate
14	S30312	Index plunger
15	S30259	Knob
16	S30458	Measuring axle
17	S30079	Nut
18	S30464	Nut
19	S30469	Outer snap ring
20	S30471	Plunger
21	S30520	Range Limiter
22	S05576	Retaining ring
23	S00489	Screw
24	S00558	Screw
25	S03482	Screw
26	S03806	Screw
27	S04134	Screw
28	S30200	Screw
29	S30027	Set screw
30	S30467	Sleeve
31	S30466	Swing plunger
32	S30465	Wire fixture

G160 measuring axle	2013
Description	Model year


6.6 G160 manual seat assembly

58 of 75




Ind.	Code	Description
1	S30452	Bolt
2	S30244	Collar
3	S30451	Cover
4	S30538	G140/G160 MAN Seat frame
5	S30541	Gas shock
6	S01805	Indexing plunger, yellow
7	S30032	Linear bearing + guide
8	S30220	Machine foot
9	S09785	Nut
10	S00558	Screw
11	S05397	Screw
12	S05787	Screw
13	S06025	Screw
14	S30256	Seat cushion
15	S30450	Seat frame
16	S30242	Seat stem
17	S30243	Seat stem cover

G160 Manual seat assy	2013
<i>Description</i>	<i>Model year</i>



Ind.	Code	Description
1	S07503	Ball bearing
2	S30452	Bolt
3	S30244	Collar
4	S30253	Collar
5	S30451	Cover
6	S30241	G140/G160 AT seat frame
7	S02035	Grip
8	S30454	Idler
9	S30245	Idler assy
10	S30246	Idler frame
11	S30035	Linear Actuator S220
12	S30032	Linear bearing + guide
13	S30220	Machine foot
14	S09785	Nut
15	S30079	Nut
16	S03099	Outer snap ring
17	S02341	RETAINING RING
18	S00558	Screw
19	S03228	Screw
20	S03482	Screw
21	S04808	Screw
22	S06796	Screw
23	S09217	Screw
24	S30200	Screw
25	S30261	Screw
26	S30453	Screw
27	S30256	Seat cushion
28	S30450	Seat frame
29	S30242	Seat stem
30	S30243	Seat stem cover
31	S30249	Spacer
32	S30247	Spring
33	S30251	Support bracket
34	S02477	Washer
35	S30252	Wire connector
36	S30250	Wire cover
37	S30248	Wire guide
38	S30260	Wire support

G160 Automatic seat	2013
Description	Model year




Ind.	Code	Description
1	S00652	Attachment
2	S00653	Bushing
3	S01144	Bushing
4	S30455	Chest support frame
5	S30280	Handle
6	S02544	Indexing plunger
7	S30232	Joint sleeve
8	S30259	Knob
9	S09785	Nut
10	S30322	Pad
11	S30456	Pivot plate
12	S04753	Rod, chest support
13	S00364	Screw
14	S00945	Screw
15	S03806	Screw
16	S06794	Screw
17	S07209	Screw
18	S09636	Screw
19	S03616	Set screw
20	S06049	Washer

Chest Support Assembly	2013
Description	Model year


7 Generation Line common parts

61 of 75


- [G110/G130 manual Hip-Fix](#)
- [G110/G130 automatic Hip-Fix](#)
- [G110/G130 manual seat](#)
- [G110/G130 automatic seat](#)
- [G110/G130 EVE arm](#)
- [Angle sensor assembly](#)
- [Measurement axle cable housing assembly](#)
- [Isometric lock control unit](#)
- [5/200kg weight stack assembly](#)
- [2.5/100kg weight stack assembly](#)
- [1/25kg weight stack assembly](#)
- [RMA 1-12 step](#)
- [RMA 1-8 step](#)



Ind.	Code	Description
1	S30042	Adjusting tube
2	S30020	Ankle support, black
3	S30044	Attachment
4	S30029	Attachment (side control)
5	S30023	Axle
6	S30037	Axle
7	S00128	Bushing
8	S30036	Cap, control lever
9	S30002	Control lever, two-finger
10	S30043	Cover
11	S02534	End cap
12	S30028	End cap
13	S00083	Flanged bushing
14	S07363	Flanged bushing
15	S30040	Foot frame, Hip-Fix man.
16	S30034	Foot pedal, black
17	S00233	Gas shock
18	S30041	Gas shock, lockable
19	S02035	Grip
20	S30022	Hip-Fix frame
21	S30061	Index sticker
22	S01805	Indexing plunger, yellow
23	S30026	Knee support
24	S30032	Linear bearing + guide
25	S30024	Mounting block
26	S01910	Outer snap ring
27	S00946	Pad, knee (hip-fix)
28	S01933	Roll pin
29	S04364	Roll pin
30	S04854	Roll pin
31	S30031	Roll pin
32	S00558	Screw
33	S00615	Screw
34	S03482	Screw
35	S04031	Screw
36	S05782	Screw
37	S06025	Screw
38	S07966	Screw
39	S30030	Screw
40	S30027	Set screw
41	S30039	Top frame, Hip-Fix
42	S30046	Top knop
43	S30045	Top tube
44	S30021	Wire, Hip-fix, L=1500




Ind.	Code	Description
1	S30020	Ankle support, black
2	S30029	Attachment (side control)
3	S30023	Axle
4	S30037	Axle
5	S00128	Bushing
6	S30036	Cap, control lever
7	S30002	Control lever, two-finger
8	S30038	Cover
9	S02534	End cap
10	S30028	End cap
11	S00083	Flanged bushing
12	S07363	Flanged bushing
13	S30008	Foot pedal frame, autom.
14	S30034	Foot pedal, black
15	S30041	Gas shock, lockable
16	S02035	Grip
17	S30022	Hip-Fix frame
18	S30033	Hip-Fix top frame
19	S30061	Index sticker
20	S30026	Knee support
21	S30035	Linear Actuator S220
22	S30032	Linear bearing + guide
23	S30024	Mounting block
24	S01910	Outer snap ring
25	S00946	Pad, knee (hip-fix)
26	S30031	Roll pin
27	S00558	Screw
28	S03228	Screw
29	S03482	Screw
30	S04031	Screw
31	S05782	Screw
32	S06025	Screw
33	S30030	Screw
34	S30027	Set screw
35	S30021	Wire, Hip-fix, L=1500




Ind.	Code	Description
1	S04497	Adjustment plate
2	S02173	Attachment
3	S05789	Attachment (seat)
4	S06592	Bushing
5	S30050	Cap
6	S00115	Cotter pin
7	S00114	Cover plate
8	S00105	Cushion plate
9	S02701	Flanged bushing
10	S00772	Gas shock
11	S09883	Guide rod
12	S00368	Handgrip
13	S30522	Lower frame
14	S00466	Nut
15	S05694	Nut
16	S09785	Nut
17	S09302	Outer snap ring
18	S30048	Pad, seat
19	S00747	Plunger
20	S00746	Release lever
21	S02974	Screw
22	S04668	Screw
23	S05185	Screw
24	S05787	Screw
25	S06340	Screw
26	S09143	Screw
27	S09217	Screw
28	S30521	Seat belt
29	S00745	Seat frame
30	S06593	Sled
31	S00023	Spring
32	S07141	Sticker, red arrow
33	S01634	Washer
34	S02477	Washer

G110/G130 Manual seat	2013
Description	Model year




Ind.	Code	Description
1	S30049	Attachment
2	S05789	Attachment (seat)
3	S30051	Back Cover
4	S00362	Belt and buckle
5	S02575	Belt and connector
6	S06592	Bushing
7	S30050	Cap
8	S00114	Cover plate
9	S00105	Cushion plate
10	S09883	Guide rod
11	S30061	Index sticker
12	S30035	Linear Actuator S220
13	S00466	Nut
14	S09785	Nut
15	S01910	Outer snap ring
16	S09302	Outer snap ring
17	S30048	Pad, seat
18	S04295	Pad, seat belt
19	S30052	Pin
20	S04031	Screw
21	S04668	Screw
22	S05787	Screw
23	S06340	Screw
24	S09143	Screw
25	S09217	Screw
26	S30521	Seat belt
27	S00745	Seat frame
28	S30047	Sled
29	S07141	Sticker, red arrow
30	S01634	Washer




Ind.	Code	Description
1	S06559	End cap
2	S30206	EVE Display unit
3	S30204	EVE Plate
4	S30203	EVE Spacer
5	S30202	EVE Strut
6	S05694	Nut
7	S06025	Screw
8	S30532	Screw
9	S30207	Screw
10	S30205	Thread block

G110/G130 EVE arm	24/2013=>
Description	Model year


7.6 Angle sensor assembly



Ind.	Code	Description
1	S30090	Cable housing
2	S06959	Cover
3	S30083	Cover sleeve
4	S30084	Mounting plate
5	S01534	Outer snap ring




Cable housing assembly	2013
Description	Model year



Ind.	Code	Description
1	S30025	Axle with thumbscrew
2	S30104	Ball joint
3	S30358	Ball joint
4	S30103	Flange
5	S00520	Flanged bushing
6	S00088	Nut
7	S07358	Nut
8	S00925	Outer snap ring
9	S30111	Plastic controller
10	S30112	Rod
11	S00191	Roll pin
12	S04461	Roll pin
13	S30113	Roll pin
14	S05782	Screw
15	S30061	Sleeve
16	S30114	Spring
17	See table	Threaded bar
18	S02528	Washer
19	S06007	Washer

7.9 5/200kg weight stack assembly



Ind.	Code	Description
1	S30055	Bushing
2	S30054	Guide rod
3	S05694	Nut
4	S00131	Pin
5	S01099	Rubber bumper
6	S06340	Screw
7	S00136	Sieve
8	S30059	Selection rod
9	S30058	Selector pin
10	S30057	Support plate
11	S30294	Top plate 5kg
12	S30293	Weight plate 5kg

5/200kg Weight Stack Assy	1/2013
Description	Model year

7.10 2.5/100kg weight stack assembly

Diagram illustrating the assembly of a 2.5/100kg weight stack. The components are numbered 1 through 15, corresponding to the parts list on the right.


Ind.	Code	Description
1	S30055	Bushing
2	S30054	Guide rod
3	S05694	Nut
4	S00131	Pin
5	S05363	Plastic washer
6	S01099	Rubber bumper
7	S06340	Screw
8	S00136	Sieve
9	S30059	Selection rod
10	S30058	Selector pin
11	S30057	Support plate
12	S30056	Top plate
13	S30071	Weight index, 2.5/100kg
14	S30053	Weight plate black+bushings
15	S30060	Weight plate Blue+bushings

2,5/100kg Weight Stack

24/2013=>


Description

Model year




Ind.	Code	Description
1	S30055	Bushing
2	S30054	Guide rod
3	S05694	Nut
4	S00131	Pin
5	S05363	Plastic washer
6	S01099	Rubber bumper
7	S06340	Screw
8	S00136	Sieve
9	S30290	Selection rod
10	S30058	Selector pin
11	S30291	Sticker
12	S30057	Support plate
13	S30289	Top plate 1kg
14	S30288	Weight plate 1kg

1/25kg Weight Stack Assy	1/2013 =>
Description	Model year



Ind.	Code	Description
1	S30063	Adjustment frame
2	S30072	Bearing
3	S30067	Flanged bushing
4	S00368	Handgrip
5	S30065	Handle
6	S30267	Index
7	S30070	Indexing plunger
8	S30068	Knob
9	S08834	Nut
10	S30073	Roll pin
11	S02974	Screw
12	S09143	Screw
13	S30064	Sled
14	S30069	Sleeve
15	S30066	Trigger



Ind.	Code	Description
1	S30268	Adjustment frame
2	S30072	Bearing
3	S30067	Flanged bushing
4	S00368	Handgrip
5	S30065	Handle
6	S30267	Index sticker
7	S30070	Indexing plunger
8	S30068	Knob
9	S08834	Nut
10	S30073	Roll pin
11	S09143	Screw
12	S30207	Screw
13	S30064	Sled
14	S30069	Sleeve
15	S30066	Trigger

RMA 1-8 step	34/13 =>
Description	Model year

David Health Solutions Ltd.

**Mannerheimintie 113, 8th floor
00280 Helsinki
Finland**

Phone: **+358 (0) 20 759 7300**

Fax: **+358 (0) 20 759 7301**

General info: **info@david.fi**

Sales: **sales@david.fi**

Support: **support@david.fi**

Website **www.david.fi**

DAVID